

Le Creuset Non-Stick Frying Pan Care Instructions

Introduction

Le Creuset Toughened Non-Stick pans are manufactured from premium materials that will provide the best in durability and cooking performance

Each pan is made from heavy gauge, forged aluminium that has been specially treated to provide a strong, toughened finish that will withstand the demands of everyday use.

Each pan spreads heat evenly and efficiently, so there are no hot spots in your cooking

The specially constructed base incorporates a magnetic, stainless steel disc that provides extra strength and stability to the pan and makes it suitable for use on ALL HEAT SOURCES including the latest induction hobs

Both the interior and exterior of each pan are finished with one of the most modern, PFOA-free, toughened non-stick finishes available providing superb release of food and easy cleaning – every day. It is an ideal surface for healthier cooking with very little oil or fat.

Optional heat-resistant glass lids are available to buy separately

Handles are secured with stainless steel rivets

Before First Use

Remove all packaging and labels, wash pans in hot soapy water, rinse and dry thoroughly.

Condition the interior non-stick cooking surface. DO NOT condition the black exterior sidewall. Rub a film of vegetable or corn oil over the entire surface using a pad of kitchen paper towels. Rinse the pan with hot water, dry thoroughly. The pan is now ready for use.

Occasional re-conditioning after this will help protect the surface and promote longer life.

Usage

Heat Zones & Sources

Le Creuset Toughened Non-Stick pans are:

- Completely multifunctional for use on any hob, under any domestic grill, or in any domestic conventional or fan assisted oven (not suitable for use in microwave ovens).
- Always match the pan base size to the hob heat zone it is to be used on. Gas flames must always be confined to the base area and NEVER extend up and around the sidewalls of the pan.
- On any glass topped hob always lift the pan on and off, or across the surface. Never slide the pan as this may cause damage to the pan base as well as to the glass.
- Use MEDIUM and LOW heat settings for the majority of cooking on all heat sources, allowing the pan to heat gradually and evenly.

- For those times when searing of meat, poultry or fish is required a medium to higher heat can be used initially, but once the pan is hot and the food added, the heat should be lowered.
- The pan should NEVER be used on a maximum or high heat setting either for pre-heating or cooking as the excessive surface temperatures will damage the non-stick cooking surface

Induction Hob Cooking

Always match the diameter of the stainless steel disc in the base of pan to the induction hob cooking zone.

Using a pan with a small stainless steel disc on too large a cooking zone may result in a weaker magnetic field being created and reduced heat output. In some cases the hob may not “recognise” the pan and no heat will be generated.

DO NOT use the boost function for longer than is required to bring the pan’s contents to a boil. The boost function should only be used for rapid heating of large quantities of water e.g. for boiling pasta or vegetables.

During cooking, you may notice some slight noise being generated in the pan by the induction hob. This will not damage the pan or affect cooking performance.

Oils and Fats

Add a little oil or fat to the cooking surface before heating begins. This will improve the flavour and browning of foods. At no time should the oil or fat be allowed to become smoking hot. If this should occur cool the pan before proceeding.

Fat-free Cooking

When cooking with no added fat or oil, pre-heat the pan on a medium setting for approximately 2 minutes before adding the food.

DO NOT leave the pan unattended during this time or allow the dry non-stick surface to overheat as permanent damage may occur.

Food Storage and Marinating

Do not store raw, marinating or cooked foods in the pans. Ingredients may cause damage to the surface.

Tools to Use

To protect your pans we recommend using Le Creuset Silicone Tools. You can also use wooden or heat resistant plastic tools.

Metal tools, spoons or balloon whisks may be used with care, but should not be used harshly or scraped over the non-stick surface. Do not knock these on the top rim of the pan.

Knives, or utensils with sharp edges, should never be used to cut foods on the non-stick surface.

Hand held electric or battery operated beaters or blenders should not be used on the non stick surface

Oven Use

Suitable for use in all types of conventional oven (not suitable for microwave ovens).

Oven safe to 260°C/500°F (220°C/425°F/Gas Mark 7 if the pan is used with a Le Creuset Toughened Non-Stick heat-resistant glass lid).

Grill Use

When used under a hot grill there should be a minimum distance of 5cm (2 inches) between the heat source and the top rim of the pan.

Handles

Handles are secured to each pan with stainless steel rivets.

Always use a dry oven glove or cloth when handling hot pans during and after cooking.

Cleaning and Storage

Cool the pan for a few minutes before cleaning. Do not plunge into, or fill with, cold water when hot.

ONLY recommended non-stick cleaning pads should be used on the non-stick surfaces. DO NOT use any metal, harsh abrasive or very stiff pads/washing up brushes, or abrasive cleaning agents on ANY of the surfaces.

The tough, reinforced non-stick coating offers excellent food release and is therefore very easy to clean. To maintain the appearance and performance of the non-stick coating, we recommend washing by hand in hot soapy water rather than cleaning in the dishwasher. This will prolong the life of the non-stick surface and enhance cooking performance

If the non-stick pan is cleaned in the dishwasher:

- Use only domestic strength dishwashing detergent (we recommend non-lemon varieties)
- The cooking surface should be re-conditioned with vegetable or corn oil before each subsequent use

Please note, prolonged, regular dishwashing may eventually mark or discolour any item of cookware and affect the release properties of non-stick surfaces. This is regarded as normal wear and tear and is not covered by the Lifetime Guarantee

If the pan is regularly washed in the dishwasher some darkening of the outer ring of the base may occur or a powdery white deposit may form. This is normal and will not affect the performance of the pan.

The surface dulling or white deposits can be removed by carefully cleaning the affected areas with a gentle nylon pad and a little water and washing up detergent. Afterwards rinse and dry thoroughly.

Misuse

The Le Creuset Lifetime Guarantee does not cover damage to the non-stick surface caused by overheating or scratching

Overheating

Damage from overheating is instantly recognisable. The non-stick surface becomes discoloured and in severe cases detaches from the pan in the form of blistering or peeling.

Scratching

Score marks or severe scratching by heavy use of metal utensils is not covered by the guarantee. Such damage is permanent and will result in the reduction of the non-stick release performance.