



1) Use a detector to check for any pipes or cables where you wish to hang your towel rail.



2) Open the pack and select the right wall plug for the wall you are attaching the towel rail to



3) Make sure the first bracket is at the desired height and mark the drill hole positions with a pencil.



4) Once more, check for any pipes or cables. Pick up your electric drill and drill the holes for the first bracket, ensuring it is slightly deeper than the length of the wall plugs.





5) Push the plugs into the freshly drilled holes, tapping them lightly with a hammer until they're flush with the wall.



6) Next, grab your screwdriver and screw the first bracket into position.



7) Using the towel rail and a spirit level, ensure the second bracket is level with the first and mark with a pencil. Check for any cables, then drill the holes and fit the bracket as before.



8) Position the towel rail over the wall brackets and secure the towel rail into place. Job done!