



1) Before drilling into the wall, use a detector to make sure there are no water or electrical cables in the way.



2) Grab a measuring tape and mark out the position of the first bracket using a pencil.



3) Pick up your electric drill and drill the holes for the first bracket.



4) Push the wall plugs into the drill holes, giving them a light tap with a hammer, if required.





5) Next, grab your screwdriver and screw the first bracket into position.



6) Use a spirit level to ensure the second bracket is level with the first and mark with a pencil.



7) Once more, check for any cables, then drill the holes and fit the bracket as before.



8) Finally, add the curtain rings and fix the poles to the brackets at each end. Job done! Now you're ready to hang your curtains.