



1) Use a detector to check for any pipes or cables where you wish to hang your Flat Screen TV.



2) Place the TV mounting bracket on the wall where you wish to hang your TV, ensuring the bracket is at the correct height.





3) Use a spirit level to ensure the bracket is horizontal and then mark the drill hole positions with a pencil.



4) Once more, check for any cables. Now, grab your electric drill and drill your holes slightly deeper than the wall plugs. If you're going into brickwork, you might want to use the hammer action on your drill.





5) Insert the wall plugs so that they're flush with the wall. Give them a light tap with a hammer, if required.



6) Next, place the bracket on the wall and fix the screws into place.





7) Fix the connector plates to the back of the TV.



8) Finally, carefully lower your TV onto the bracket, ensuring it's secured in place. And that's it, job done – happy viewing!