

HOW TO

**EZY
PZY**

CURTAIN POLE KIT



1

Before drilling into the wall, use a detector to make sure there are no water or electrical cables in the way.



2

Grab a measuring tape and mark out the position of the first bracket using a pencil.



3

Pick up your electric drill and drill the holes for the first bracket.



4

Push the wall plugs into the drill holes, giving them a light tap with a hammer, if required.



5

Next, grab your screwdriver and screw the first bracket into position.



6

Use a spirit level to ensure the second bracket is level with the first and mark with a pencil.



7

Once more, check for any cables, then drill the holes and fit the bracket as before.



8

Finally, add the curtain rings and fix the poles to the brackets at each end.
Job done! Now you're ready to hang your curtains.