



1) Firstly, use a detector to check there are no cables or pipes around the area you want to put the shelf up.



2) Then hold the shelf up to the wall to gauge height and position. Using the underside of the shelf as a guide, mark the height with a pencil. You may need someone to give you a hand with this.





3) Grab a spirit level and a pencil and draw a faint line the length of the shelf. This will act as a guide for the top of the brackets.



4) Next, take the left wall bracket and place it on the line, using your spirit level to check that it's vertical. Mark the hole positions with a pencil. Do this for both brackets.





5) Grab your electric drill and drill the holes slightly deeper than the wall plugs in the kit.



6) Insert the wall plugs until they're flush with the wall, giving them a light tap with a hammer if needed.





7) Screw both of the brackets into place.



8) Finally, fit the shelf, securing it to the brackets on the underside with a small screw. And that's it – job done!