

## Installation

- Lubricate the o-rings of adaptor with silicon based grease.
- Cut the tube not supplied protruding through the wall to length required for adaptor to finish against wall
- 3. Slide adaptor over the tube.
- 4. Place basin trap under basin waste and tighten locking nut to basin waste.
- Loosen adjustor nut and adjust height of trap so that the back water exit is in position to allow for around 5 degree fall back to the wall, then tighten locking nut.
- 6. Cut chrome pipe to length required to fit between the back of the basin trap and the adaptor.
- 7. Remove basin trap from basin waste.
- 8. Push and twist chrome pipe fully into adaptor.
- 9. Loosen back nut and remove the o-ring. Then place this nut and o-ring over the end of chrome pipe.
- 10. Slide the back water exit of the basin trap over the chrome pipe, then slide back nut and o-ring into position and tighten.
- 11. Place the locking nut to the basin waste and tighten.

## **Maintenance**

We do NOT recommend you use any household cleaners to clean the product. The product should only be cleaned with soapy water, rinsed with clean water, and dried with a soft cloth.

## **INSTALLATION INSTRUCTIONS**



For any further information please contact Bathstore on: **0845 873 8843** 

Or visit our web-site at www.bathstore.com The manufacturer reserves the right to make technical modifications without prior notice.