

FITTING INSTRUCTIONS - CONCRETE FLOOR

STANDARD FIT

FLUSH FIT

WET ROOM

CONTENTS

*Important Information - See Below - Please Read First Prior To Installation

Standard Fit 1 - 6

Flush Fit 7 - 10

Off The Floor Plinth 11

Wet Room 12

Doors/Screens And Shower Heads 13

STEPS

1 - 6

7 - 10

11

12

13

1 - STANDARD FIT - STEPS 1-6

1

2

3

4

5

6

1

2

3

4

5

6

1

2

3

4

5

6

STANDARD FIT

FLUSH FIT

WET ROOM

7

8

9

10

1

2

3

4

5

6

1

2

3

4

5

6

*IMPORTANT INFORMATION - PLEASE READ FIRST

- This tray is handmade from natural materials. It is possible it may not be perfectly flat (approx 4mm tolerance) or may vary in thickness.
- Check the product thoroughly prior to fitting. Unfortunately no claims for imperfections can be made once the tray has been installed.
- The tray must be fitted STRICTLY in accordance with the installation instructions. Failure to fit and maintain the product as per the instructions will invalidate the guarantee and possibly lead to long term damage.
- The use of any materials other than those specified in the fitting instructions could result in the shower tray to fail, invalidating the guarantee.
- Fit ONLY the waste unit supplied. Fitting any other waste unit may lead to a reduction in water flow.
- This shower tray and waste unit combine to achieve European EN124 approval for water drainage. They are designed to provide a water flow of over 20 litres per minute. Failure to fit the waste unit provided exactly in accordance with the fitting instructions (see enclosed within the 'Information Pack') may reduce water flow and create drainage problems.
- For cleaning information refer to the 'Cleaning and Maintenance' section of the accompanying 'Information Pack'.
- If this product has been fitted as part of a wet room, see 12. If it has been fitted as part of an enclosure, see 13 for help with the location of the shower head and glass screens. This will help prevent unwanted wet areas in your bathroom.
- Do not allow any items such as hairnets, sponges etc., to obstruct the waste cover during showering, this could lead to overflowing.

11 - OFF THE FLOOR PLINTH

For more problematic plumbing situations, a comprehensive 'Fitting Kit' is available. This raises the tray off the floor to provide a simpler plumbing solution. For further details, see your retailer or installer.

12 - WET ROOM APPLICATION

Instructions 1-11 cover all showering applications which include a shower door or screen.

If your tray has been purchased to be fitted as part of a wet room area with no surrounding glass, the following instructions apply:

Fit your tray in accordance with the 'Standard Fit' instructions (above steps 1-6) and in conjunction, incorporate a proprietary wet room tanking system.

See your retailer/installer for full details.

13 - DOORS/SCREENS AND SHOWER HEADS

Always fit a door or screen unless fitting as part of a wet room - See fig 1 and refer to section 12

Never fit a shower head at the open end of an enclosure - See figs 2/3/4

When fitting a walk in front screen only, ensure that the screen is centrally located and approximately 3/4 the length of the tray - See fig 3

If fitting a side screen or the tray is adjacent to a wall, ensure that front screen is at least approximately 2/3 the length of tray - See fig 2 or 6

Always fit a front screen unless fitting as part of a wet room - See fig 5

Always fit full enclosures to 900x900 square and 900 quadrant trays - See fig 4/6

Fig 1 - No Panel/Enclosure

Fig 2 - Walk In - Front & Side Panel

Fig 3 - Walk In - Center Panel

Fig 4 - Square - Full Enclosure Only

Fig 5 - Two End Panels

Fig 6 - Walk In - Front Panel

Fig 7 - Door Enclosure

Fig 8 - Quadrant - Full Enclosure Only

FITTING INSTRUCTIONS - WOOD FLOOR

STANDARD FIT

FLUSH FIT

WET ROOM

CONTENTS

*Important Information - See Below - Please Read First Prior To Installation

Standard Fit 1 - 6

Flush Fit 7 - 10

Off The Floor Plinth 11

Wet Room 12

Doors/Screens And Shower Heads 13

STEPS

1 - 6

7 - 10

11

12

13

1 - STANDARD FIT - STEPS 1-6

1

Take care to avoid chipping on bottom edges/corners when moving the tray into position.

Placing the tray in position, mark the floor boards by drawing around the tray. Mark out the center of the waste hole.

Move the tray to a safe location to prevent accidental damage.

2

Template supplied

It is recommended that a professional plumber completes the plumbing installation.

It is essential to use the template supplied to mark out the waste hole.

Lift the floor boards to plumb the waste and trap (see 'Template and Waste Guides').

4

Prior to mixing sand and cement, sweep clean the area.

Ensure no gaps between floor boards. All gaps should be sealed with joint tape or similar.

Mix sand and cement (5/1 ratio) adding anti-cracking agent, such as 'Fibermix' and spread to fill entire marked area with approximately 10-15mm mortar screed.

Ensure that the whole area under the tray is fully covered by the mortar screed. Any unsupported area could lead to cracking.

5

24 HOURS DRYING TIME

Ensure to level the tray on all outer edges.

Apply a bead of silicone along the center of each edge of the tray to be fitted against the walls.

Lay the tray in position, push against the wall and bed down onto the mortar screed. Ensure all of the base is supported by the cement. Level the tray from each edge.

Leave for 24 hours prior to next step.

3

It is essential that the floor boards are properly secured, ensuring no movement or flex. Any joints in the floor boards that are not supported by a joist must be supported by separate noggin(s). Any floor boards that show flexing between joints MUST also be supported by additional noggin(s).

Ensure that floorboards around the waste hole are fully supported by noggin(s). There must be no floor movement around the cut hole.

Fit the lifted floor area. Secure all floor boards under the tray with two wood screws at every point they cross a joist or a noggin.

6

It is recommended that a professional plumber completes the plumbing installation (see 6i) - refer to 'Template and Waste Guides' provided.

The walls down to the tray, leaving a 5mm gap between the tray and the wall (see 6ii).

Apply a bead of mould resistant silicone sealant between the floor and tray and along the back edge of the tray up to the bottom of the last tile (see 6ii).

Finally, fit your chosen flooring (as appropriate) and apply a bead of mould resistant silicone between the shower tray and your chosen floor (see 9 for guidance).

STANDARD FIT

FLUSH FIT

7 - FLUSH FIT - STEPS 7-10

Firstly, install tray as per steps 1-6

Screw down marine ply onto the floor boards ensure it is the appropriate thickness so the tiling fits flush with the edge of the tray. Apply silicone between the marine ply and tray, also approximately 1" along any joint that meets the tray edge(s).

8

Finish tiling ensuring a flush finish with the shower tray. Ensure that waterproof adhesive and grouting are used. Do not grout between the shower tray and adjacent tiles.

9

Fill

Ensure all edges are siliconed properly.

Apply a bead of mould resistant silicone between the shower tray and adjacent tiles.

10

Waste cover is designed to be easily removed allowing access to waste trap.

Place the waste cover into the tray (it does not use any adhesives).

Fit shower door/screen and shower head as per diagram 13.

11 - OFF THE FLOOR PLINTH

12 - WET ROOM APPLICATION

*IMPORTANT INFORMATION - PLEASE READ FIRST

- This tray is handmade from natural materials. It is possible it may not be perfectly flat (approx 4mm tolerance) or may vary in thickness.
- Check the product thoroughly prior to fitting. Unfortunately no claims for imperfections can be made once the tray has been installed.
- The tray must be fitted STRICTLY in accordance with the installation instructions. Failure to fit and maintain the product as per the instructions will invalidate the guarantee and possibly lead to long term damage.
- The use of any materials other than those specified in the fitting instructions could result in the shower tray to fail, invalidating the guarantee.
- Fit ONLY the waste unit supplied. Fitting any other waste unit may lead to a reduction in water flow.
- This shower tray and waste unit combine to achieve European EN1247 approval for water drainage. They are designed to provide a water flow of over 20 litres per minute. Failure to fit the waste unit provided exactly in accordance with the fitting instructions (see enclosed within the 'Information Pack') may reduce water flow and create drainage problems.
- For cleaning information refer to the 'Cleaning and Maintenance' section of the accompanying 'Information Pack'.
- There should be no movement in any wooden surface supporting the tray (see fig 3 - Wooden floor installation). Any movement should be prevented by adding noggin between floor joists where necessary. Any movement beneath the tray will eventually lead to cracking and will invalidate the guarantee.
- If this product has been fitted as part of a wet room, see 12. If it has been fitted as part of an enclosure, see 13 for help with the location of the shower head and glass screens. This will help prevent unwanted wet areas in your bathroom.
- Do not allow any items such as flannels, sponges etc., to obstruct the waste cover during showering. This could lead to overflowing.

11 - OFF THE FLOOR PLINTH

For more problematic plumbing situations, a comprehensive 'Fitting Kit' is available. This raises the tray off of the floor to provide a simpler plumbing solution. For further details, see your retailer or installer.

12 - WET ROOM APPLICATION

Instructions 1-11 cover all showering applications which include a shower door or screen.

If your tray has been purchased to be fitted as part of a wet room area with no surrounding glass, the following instructions apply:

Fit your tray in accordance with the 'Standard Fit' instructions (above steps 1-6) and in conjunction, incorporate a proprietary wet room tanking system.

See your retailer/installer for full details.

See your retailer/installer for full details.

13 - DOORS/SCREENS AND SHOWER HEADS

Always fit a door or screen unless fitting as part of a wet room - See fig 1 and refer to section 12

Never fit a shower head at the open end of an enclosure - See fig(s) 2/3/6

When fitting a walk in front screen only, ensure that the screen is centrally located and approximately 3/4 the length of the tray - See fig 3

If fitting a side screen or the tray is adjacent to a wall, ensure that front screen is at least approximately 2/3 the length of tray - See fig 2 or 6

Always fit a front screen unless fitting as part of a wet room - See fig 5

Always fit full enclosures to 900x900 square and 900 quadrant trays - See fig 4/6

Wall

Shower Head

Shower Door/Screen

Fig 1 - No Panel/Enclosure

Fig 5 - Two End Panels

Fig 2 - Walk In - Front & Side Panel

Fig 6 - Walk In - Front Panel

Fig 3 - Walk In - Center Panel

Fig 7 - Door Enclosure

Fig 4 - Square - Full Enclosure Only

Fig 8 - Quadrant - Full Enclosure Only