

TrayMate



W H I T E S T O N E

S I M P L E L O G I C A L T H I N K I N G

FOR FULL ADVICE AND INFORMATION GO TO

www.traymateproducts.com



WHITESTONE

Shower Tray Installation Instructions

50
YEAR GUARANTEE
HANDMADE SHOWER TRAYS

It is essential that your shower tray is fitted **STRICTLY** in accordance with these instructions. Failure to install and maintain the product as per instructions will invalidate the guarantee.

General: Handle with care, stone resin shower trays are very fragile. Please note that the fitting of this product will be taken as acceptance of quality and colour match. Unfortunately no claims for imperfection can be accepted after fitting.

Fitting instructions: Important: Stone resin shower trays **MUST** be entirely supported on a strong base and laid upon a screed of sand and cement. Please ensure that no area beneath the tray is unsupported. If not, it is liable to crack through impact or prolonged use.

Wooden Floors - Cover floor boards with a sheet of marine ply (18mm or thicker) cut to the exact size of shower tray & cut a hole just large enough to fit waste and backing nut. **Note:** Hole should be no more than 10mm larger than backing nut to prevent cracking around waste area.

Bond or screw ply sheet to floor boards and cover with a 10mm – 20mm screed of 5:1 mix sand, cement and anti crumbling agent such as 'Feb' mix.

Lay the tray onto a cement bed and level from the top edges with a spirit level. Ensure that the base of the tray is entirely bedded into the cement. Do **not** leave any part of the underside of the tray unsupported by cement or your tray will crack in time.

Stone floors

Option 1 - Fitting your Whitestone shower tray with the waste trap below ground.

Channel floor to accommodate waste, screed with sand and cement and level from top edge as above.

Option 2 - Raising your Whitestone shower tray off the floor to allow access to the waste trap.

A. Simply purchase a pre-built factory made 'TrayMate Fitting Kit'. Everything is included within the kit. This is the simplest and most effective method of installing your Whitestone shower tray. Includes: wooden plinth (pre-cut waste), steel legs, bedding adhesive, side panels and clips (see website for full details).

or

B. Self-build a wooden plinth to allow access to waste. This should be constructed in 4"x 2" timber with no more than 6" centers. Cover the plinth with 18mm or thicker marine ply and fit as per 'wooden floors' instructions.

Cleaning and Maintenance - Clean regularly with a damp cloth or sponge followed by a soft dry cloth. Occasionally use a *non-abrasive* cleaner to remove stubborn stains and buff with car polish annually to give a perfect finish. **Do not use stiff brushes or abrasive cleaners, as these will damage the surface of the tray.** Small chips and marks can be repaired with our shower tray repair kits. Please ask your retailer for more details. In hard water areas, limescale will mark the surface of the tray. To prevent this, use good quality water softener. The use of rubber mats may cause a reaction with the surface of the tray and therefore is not recommended. Some hair dyes may mark the surface of the tray if not fully washed away.

Steam Generators - Stone resin shower trays can accommodate steam generators but please note that the steam must not be aimed directly on to the surface of the shower tray. The resulting high temperatures can cause thermal shock and lead to serious damage to the tray. Position the steam head at least 40cm from the surface of the shower tray and ensure that the manufacturers recommended steam dispersal unit is fitted to the steam head.

Guarantee Registration Form

To ensure that your shower tray guarantee is valid, the tray must be fitted in accordance with the manufacturers instructions attached. (for further information visit www.traymateproducts.com)

Name: _____

Address: _____

Telephone: _____

Email: _____

Size of tray: _____ Colour: _____

Date Purchased: ____/____/____

Retailer: _____

I confirm that my shower tray has been fitted in accordance with the above instructions and understand that failure to do so will invalidate my guarantee.

Signature: _____

Please sign and return this guarantee within one month of purchase to:

TrayMate Products Limited
Ensign Estate, Botany Way, Purfleet, Essex RM19 1TB

FOR FULL ADVICE AND INFORMATION GO TO www.traymateproducts.com