


Liquid Hinge Door and Side Panel Installation Instructions

Hinge door in alcove (see pages 3 ~ 6)




- Prior to installation check that all fittings have been supplied.
- The tray should be level, the walls should be tiled down to the tray, and the horizontal joint between the tiles and tray must be sealed with silicone sealant to ensure water-tightness.
- Handle with care, Impacts can damage both the glass and the frame.
- Please check for any hidden pipes or cables before drilling holes in the wall.
- The success of the installation and operation is, of course, dependant on the squareness, alignment and construction of the walls to which the enclosure is fixed.
- The enclosure is reversible: " door can be either left or right opening."
 In the remainder of this instruction the illustrations will only show the left hand installation of the hinge door.
- The wall fixings supplied may not be suitable for your installation. You may need to source alternatives depending on the construction of the wall you are fixing to.
- During the installation of the glass panels, the UP/ARROW indicator should always be positioned at the top.
- Note that all screws which pass through glass are supplied with clear plastic sleeves. It is important that these are fitted as the glass can be badly damaged if unprotected screws are in contact with it.

Tools Required:




- 11 E







2 - 11


















bathstore














bathstore



































































10 - 11 E



If the gap between the wall and glass is less than 5mm please apply silicone sealer. If the gap exceeds 5mm please follow steps of step 1a-6a.

