

#### **↑** PRECAUTIONS ON USE

- Check periodically to ensure that the light unit is attached securely.
- Do not use a damaged rubber band.
- Stop your bicycle to operate the switch.Keep the light away from children.

light inside a vehicle or near a heater.

- Charging, discharging, and storing in high temperatures will cause the rechargeable battery to deteriorate faster. Do not place the
- This unit is not totally waterproof. Please wipe and dry it completely after using in rain.
  Otherwise, it may cause failure.
- If the light unit or parts become dirty with mud, etc., clean with a soft cloth which is moistened with mild soap. Never apply paint thinner, benzine or alcohol; damage will result.

#### **↑** PRECAUTIONS ON CHARGING

- We recommend using 500+mA (USB2.0) USB battery charger.
- Avoid charging in direct sunlight or in a vehicle parked under direct sunlight, and make sure to charge only when the ambient temperature is between 5 and 40°C (41°F and 104°F).
- Before charging, be sure that no dust or other foreign objects attach to the USB plug.
- Do not subject the light to vibrations while charging.
- When your PC is in sleep state, the unit cannot be charged.
- Once charging is complete, be sure to disconnect the USB plug.
- Charging and lighting times are approximate values, and will vary by environmental and user conditions.
- If the illumination time is significantly reduced even after proper charging, the rechargeable battery may be nearing the end of its service life. Dispose of the battery as described in "PRECAUTIONS ON DISPOSAL".

### **⚠ STORAGE PRECAUTIONS**

Cool and dry storage is recommended. For long period storage, it is important to charge the battery 30 minutes every 6 months.

#### **⚠ PRECAUTIONS ON DISPOSAL**

When disposing of the light unit, remove the internal rechargeable battery and dispose of it according to local regulations.



Light unit



USB cable








Rubber band Shade sticker (Large/Small) \* Front model (Clear lens) only


# 1 HOW TO CHARGE

Always charge the product before use.



## 2 HOW TO MOUNT

Attach securely in the mounting position.




#### **OPTION: Rubber base for Sharp Aero**


For posts with a more acute angle, use the rubber base for Sharp Aero.

\* Rear model (red lens) only





### HOW TO USE



### **SPECIFICATIONS**

Battery : Rechargeable lithium-ion polymer battery

Temperature range:  $14^{\circ}F - 104^{\circ}F$  (- $10^{\circ}C - 40^{\circ}C$ )

Recharge/discharge number of times:

About 300 times

(until the rated capacity drops to 70%)

Dimensions/weight: 2-59/64" x 1-13/64" x 1-19/64" (74.4 x 30.5

x 32.9 mm) / 1.08 oz (30.5 g)

The specifications and design are subject to change without notice.

### LIMITED WARRANTY

2-year Warranty: Light unit only (excludes battery deterioration) CatEye products are warranted to be free of defects from materials and workmanship for a period of 2 years from original purchase. If the product fails to work during normal use, CatEye will repair or replace the defect at no charge. Service must be performed by CatEye or an authorized retailer. To return the product, pack it carefully and enclose the warranty certificate (proof of purchase) with instruction for repair. Please write or type your name and address clearly on the warranty certificate. Insurance, handling and transportation charges to CatEve shall be borne by person desiring service.

For UK and REPUBLIC OF IRELAND consumers, please return to the place of purchase. This does not affect your statutory rights.

[For US Customers]

CATEYE AMERICA, INC.

2825 Wilderness Place Suite 1200,

Please register your CatEye product on the website. http://www.cateye.com/en/support/regist/

#### CAT EYE CO., LTD.

2-8-25, Kuwazu, Higashi Sumiyoshi-ku, Osaka 546-0041 Japan Attn: CATEYE Customer Service

Section

Boulder CO 80301-5494 USA Phone: (06)6719-6863 Phone : 303.443.4595 Fax : (06)6719-6033 Toll Free: 800.5.CATEYE E-mail: support@cateve.co.jp Fax 303.473.0006 URL: http://www.cateye.com E-mail : service@cateye.com

# **SPARE / OPTIONAL PARTS**



5447010 Rubber band



5447030 Rubber base



5342470 Spacer X



5342730 USB cable (MICRO USB)



5342460 Clip (C-2)



5447040 Rubber base for Sharp Aero